



PATRIOT TIMBER

P R O D U C T S[®]

the revolutionary source[®]

The Flex and Look Test

Follow these steps:

- 1) Stand the panel vertically with its 4' edge on the floor and the panel face towards you (the *RightPly*[™] plywood stickers are on the back of the panel).
- 2) Grip the top panel edge with one hand and firmly place the palm of your other hand against the face of the panel.
- 3) Pull the panel down approximately 4" - 8" with your top hand while simultaneously pressing forward with the palm of your other hand approximately 4" - 8" until a noticeable curve is in the panel. Hold this position during inspection.
- 4) With the panel in this flexed position, thoroughly inspect the entire panel surface for imperfections, which will look like "bubbles" or "creases". In the rare instance you find such an imperfection, do not use the panel. Set it aside and contact Patriot Timber Products immediately for a resolution.



panel products from patriot timber

RightPly[™] U.S. Patent
8,414,996
Premium Plywood