



panel products from patriot timber

RevBead[®]

U.S. Patents
8,414,996 and
9,242,391

Reversible Plywood Beadboard



panel products from patriot timber

PatriotBead[®]

U.S. Patents
8,414,996 and
9,242,391

Plywood Beadboard

Installation Recommendations

Before you start your plywood beadboard panel installation, it is important to note the following points contained in these Installation Recommendations:

- All panels should be acclimated to the installation environment at least 24-48 hours prior to use.
- Mark and cut on the backside of the panel to ensure a smooth edge.
- Please note and follow fastening schedule based on your application.
- Drywall is not a suitable backing and will not hold fasteners.
- Installation requirements can vary from jobsite to jobsite. These are our recommendations for installing **RevBead[®] Reversible Plywood Beadboard** and **PatriotBead[®] Plywood Beadboard**.
- Our warranty only covers panel failure due to delamination. Please see full panel warranty for additional information.

Installation Recommendations for Walls and Ceilings:

Panel Preparation

- Care should be taken during handling and storage of panels in order to prevent damage to shiplap edges, face, or back.
- Acclimate in the installation environment for 24 - 48 hours. Do not expose panels to direct weather or sunlight during the acclimation period.
- In order to minimize dimensional panel movement (shrinkage, swelling, warp, or bow), panels should be stacked flat on a level surface with ample spacing between sheets for proper support and air flow. Use at least 3 or 4 spacers at even intervals as shown in Figure 1.



Figure 1

- Examine each panel using the **Flex & Look Test** using the following steps.
 1. Stand each sheet of beadboard vertically with its 4' edge on the floor and the panel face towards you.
 2. Grip the top panel edge with one hand and firmly place the palm of your other hand against the face of the panel.
 3. Pull the panel down approximately 4"-8" with your top hand while simultaneously pressing forward with the palm of your other hand approximately 4"-8" until a noticeable curve is in the panel. Hold this position during inspection.
 4. With the panel in this flexed position, thoroughly inspect the entire panel surface for imperfections, which will look like "bubbles" or "creases". In the rare instance you find such an imperfection, do not use the panel. Set it aside and contact Patriot Timber Products immediately for a resolution.
- Measure your wall or ceiling surface to determine where panels will need to be cut both horizontally and vertically in order for panel edges to align with a backing that can hold fasteners (studs, furring strips, blocking, wood substrate, etc).
 - *Drywall is not a suitable backing and will not hold fasteners.*
- When preparing to cut panels for installation, be sure to use the correct blade (cross-cut, rip, or combination blade) so that your cut edges are smooth and splinter free. Sand edges as needed.
- Measure and mark the backside of each panel for door, window, electrical outlet, and heat register cut-outs as needed. Double check your measurements before cutting (measure twice, cut once!). Make all of your cuts on the backside of the panel.

Panel Fitting & Installation for wall paneling/wainscoting applications:

- Make the necessary cut-outs for doors, windows, electrical outlets, heat registers, etc.
- Begin your installation by loosely fitting the panel into the starting corner leaving a 1/4" expansion gap at the top and bottom of the wall and an 1/8" expansion gap around all cut-outs. Mouldings and/or outlet covers will conceal all expansion gaps.
- The leading panel edge must correctly align with the center line of the stud or furring strip to ensure all subsequent panels line up correctly during the balance of the installation.
- Construction adhesive may be used in conjunction with fasteners to properly secure the panels as shown in Figure 2.



Figure 2

- Panels should be fastened 6" on center at ends and edges and 12" on center on studs and furring strips in the panel field. Fasten through the bottom shiplap edge that is flush with the wall. When fastening the top shiplap, pay special attention to stagger fasteners so as not to align with the bottom shiplap fasteners.
- Continue this method with all panels being installed.
- Allow for expansion between panels by lightly butting or leaving approximately a 1/32" gap for interior applications or 1/8" for exterior weather protected applications.
- Use a minimum 2" finishing or ring-shank paneling nail (6d) for interior applications.
- Slightly counter-sink fasteners with hammer and nail set or adjust the depth of drive on your pneumatic nail gun. Be careful not to damage the surface of the panel with your preferred method of fastening.
- To complete your installation, install mouldings and use putty or wood patch to fill fastener holes. Paint or stain as desired.

Panel Fitting & Installation for ceiling applications:

- Make the necessary cut-outs for ceiling fixtures such as lights, fans, etc.
- Begin your installation by loosely fitting the panel into the starting corner leaving a 1/4" expansion gap where the walls meet the ceiling and an 1/8" expansion gap around all cut-outs.
- The leading panel edge must correctly align with the center line of the trusses/rafters/joists to ensure all subsequent panels line up correctly during the balance of the installation.
- Some amount of blocking will be needed to securely and properly attach the beadboard to your trusses/rafters/joists. Blocking should be placed between trusses/rafters/joists as needed for subsequent fastening.
- Panels should be fastened 6" on center at ends and edges and 12" on center on trusses/rafters/joists in the panel field. Fasten through the bottom shiplap edge that is flush with the wall. When fastening the top shiplap, pay special attention to stagger fasteners so as not to align with the bottom shiplap fasteners. Continue this method with all panels being installed.
- Allow for expansion between panels by lightly butting or leaving approximately a 1/32" gap for interior applications or 1/8" for exterior weather protected applications.
- Use a minimum 2" galvanized casing nail (6d) for exterior ceiling applications or a minimum 2" finishing or ring-shank paneling nail (6d) for interior ceiling applications.
- Slightly counter-sink fasteners with hammer and nail set or adjust the depth of drive on your pneumatic nail gun. Be careful not to damage the surface of your panel with your preferred method of fastening.
- To complete your installation, install mouldings or trim and use putty or wood patch to fill fastener holes. Paint or stain as desired.

*For weather protected ceiling applications (such as porch ceilings), a vapor barrier should be placed between the panel and the studs, furring strips, wood substrate, etc.

**Installation requirements can vary from jobsite to jobsite. These are our recommendations for installing *RevBead*[®] plywood and *PatriotBead*[®] plywood. Our warranty only covers panel failure due to delamination.



PATRIOT TIMBER
P R O D U C T S[®]
the revolutionary source[®]

Post Office Box 19065 • Greensboro, North Carolina 27419 • Telephone 336.299.7755 • Facsimile 336.299.4050
www.PatriotTimber.com

Installers and purchasers are solely responsible for evaluating job conditions, building and safety codes, necessary installation tools, hardware and finishing products, any manufacturer recommendations and the end-use application to determine the suitability of *RevBead*[®] plywood and *PatriotBead*[®] plywood.
© Copyright 2019 Patriot Timber Products, Inc.

All other products or company names referenced may be trademarks or registered trademarks of their respective companies.