



## Frequently Asked Questions

- 1. Question:** What are the advantages to choosing *RevolutionPly*® plywood over Meranti plywood and Lauan/Luan plywood?

**Answer:** *RevolutionPly*® plywood is manufactured from plantation and sustainable wood sources and is a far better alternative to Meranti plywood and Lauan/Luan plywood that originates from poorly managed tropical rainforests. *RevolutionPly*® plywood is a higher quality panel than Meranti plywood and Lauan/Luan plywood. *RevolutionPly*® panels have a consistent appearance from piece to piece, a blemish-free face, and the best packaging in the industry.
- 2. Question:** What are the most common uses of *RevolutionPly*® plywood?

**Answer:** *RevolutionPly*® plywood is ideal for a variety of applications, including flooring underlayment, paneling, millwork, and woodworking projects.
- 3. Question:** Can *RevolutionPly*® plywood be used in an exterior application?

**Answer:** No. *RevolutionPly*® panels are designed for interior applications only. They are not for direct exterior exposure.
- 4. Question:** How do you perform the Flex and Look Test?

**Answer:** Go to Patriot Timber's Flex and Look Test page to see the 4 simple steps or to watch a short video. The Flex and Look Test is an important procedure that only takes a few seconds and should be applied to any panel prior to use. Flexing the panel will help to reveal any delamination or core irregularities. In the rare instance you find such an irregularity, do not use the panel. Set it aside, and contact Patriot Timber Products immediately for a resolution.
- 5. Question:** Which side of the panel goes face down in flooring underlayment applications?

**Answer:** The *RevolutionPly*® panels should be installed with the label facing down towards the structural subfloor.
- 6. Question:** For flooring underlayment applications, can screws be used when fastening *RevolutionPly*® plywood to the subfloor?

**Answer:** Yes, you can use coated flathead wood screws. Do not use drywall screws. Make sure the screw selected has a minimum 3/16" diameter head. The screw you choose should not penetrate through the bottom of the subfloor. To correctly secure *RevolutionPly*® panels to the subfloor, the minimum spacing requirement between each fastener is every 4" on center in the body of the panel and every 2" along the panel perimeter. This will eliminate potential flooring issues resulting from insufficient and incorrect fastener placement.
- 7. Question:** How do I attach/fasten *RevolutionPly*® plywood for wall paneling or wainscot applications?

**Answer:** *RevolutionPly*® plywood can be installed directly to wall studs as well as placed over a solid wall surface such as existing sheetrock, paneling or other wall covering. Blocking and bracing is recommended if you are installing directly to studs, as there may be some flex in the wall panel surface. Construction adhesive can be used in conjunction with fasteners (nails, narrow crown staples) in order to properly secure the panels. 1.5" finishing nails, 4d ring shank paneling nails, or 1/4" x 1.5" narrow crown staples are recommended. *RevolutionPly*® plywood should be fastened every 6" on center along the panel ends and edges and 12" on center over wall studs in the panel field.
- 8. Question:** For flooring and paneling applications, how long should the *RevolutionPly*® panels acclimate at the installation site before being used?

**Answer:** *RevolutionPly*® panels should acclimate 24 to 48 hours in a heated home environment of approximately 70 degrees Fahrenheit.





panel products from patriot timber

# RevolutionPly®

U.S. Patents 8,414,996 and 9,242,391

## Frequently Asked Questions

**9. Question:** Should *RevolutionPly*® panels be glued to the subfloor?

**Answer:** No. Do not glue *RevolutionPly*® panels to the subfloor. Gluing underlayment panels to the subfloor can cause problems such as a tack and release floor that crackles when you walk across it. In addition, gluing the underlayment panels to your structural subfloor will eliminate the opportunity to remove the underlayment for a future floor replacement. We do not warrant our underlayment panels that have been glued to the subfloor.

**10. Question:** Is *RevolutionPly*® plywood environmentally friendly?

**Answer:** Yes. All the wood veneers in *RevolutionPly*® plywood come from plantation and sustainable wood sources. *RevolutionPly*® plywood contains no tropical hardwoods or species from endangered forests. *RevolutionPly*® plywood is certified for points toward ICC-700 National Green Building Standard™ (NGBS).

**11. Question:** What is the best way to remove the label from the backside of the *RevolutionPly*® panel?

**Answer:** We have found the easiest method is to heat the label with a hairdryer prior to removal. If there is any residual adhesive, you can remove it using either Naphtha, Goo Gone®, or mineral spirits.



**PATRIOT TIMBER**  
P R O D U C T S®  
the revolutionary source®